

Addressable Fire Systems



XFP



XFP 1-2 LOOP ADDRESSABLE FIRE PANELS TO EN54-2/4 & ANCILLARIES

Order Code	Description
XFP501E/CA	XFP 1 loop 16 zone panel, C-TEC CAST. Max. 2 x 3.2Ah batteries
XFP501/CA	XFP 1 loop 32 zone pane, C-TEC CAST. Max. 2 x 7Ah batteries
XFP502/CA	XFP 2 loop 32 zone panel, C-TEC CAST. Max. 2 x 7Ah batteries
XFP510-16	XFP Repeater panel, 16 zones (all protocols). Max. 2 x 3.2Ah batteries
XFP510-32	XFP Repeater panel, 32 zones (all protocols). Max. 2 x 7Ah batteries
CFP761	CFP/XFP network communications card for XFP 16 zone panels
AFP711	CFP/XFP network communications card for XFP 32 zone panels
XFP385	Flush mounting bezel (for XFP 32 zone masters & repeaters)
BF359/3S	Stainless steel glazed enclosure for XFP 32 zone panels.
BF359/3CL	Cam lock kit for BF359/3S stainless steel enclosure
BF359/3SL	Electromag solenoid lock kit for BF359/3S stainless steel enclosure
AFP709	XFP printer kit (printer, lead & socket) for XFP 32 zone panels
CA507	XFP CAST Programming software c/w SAF7070000 lead
SAF7070000	2m Programming lead (4 way molex to 9-way RS232 'D' female)
BF232	RS232 to USB convertor
S-KEY	Spare key for use with XFP single loop 16 zone panels



XFP501E/CA



XFP501/CA & XFP502/CA

CAST HANDHELD PROGRAMMER

Order Code	Description
CAPROG	CAST Handheld programmer



CAPROG

CAST MANUAL CALL POINTS TO EN54-5/17

Order Code	Description
CA470	CAST red manual call point, universal mounting
BF370SC	Protective cover for CA470 manual call point
CA47067	CAST red IP67 manual call point, surface mounting

Yellow (CA470Y), green (CA470G), blue (CA470B) & white (CA470W) call points also available



CA470

CAST DETECTORS TO EN54-5/7/17

Order Code	Description
CA416	CAST Optical Smoke Detector
CA402	CAST Programmable Heat Detector
CA414	CAST Programmable Multisensor Fire Detector
CA408	CAST Detector Base
CA408R	CAST Relay Base



CA408